



You should have

- SpaceKraft Tote ready for dispensing product
- Ball Valve Assembly
- Quick Connect (Part No. VFQCF01 or VFQCFGF01)
- Hose
- Tilt Table (Optional)



Ball Valve Assembly



1

Here's what to do

- 1 Remove the fitment cap and thread on the ball valve assembly.
- 2 Ensure the valve is in the opened position, push handle of the cutter tool extending the plunger into bag, then withdraw.
- 3 Close the valve and unthread the cutter tool. A few ounces of product will be released; this is normal, a rag or small cup can be used to catch this.

continues on next page



2



3



4

- 4 Thread on the quick connect fitting and attach your hose.
- 5 Open the valve and begin dispensing.
- 6 When empty, dispose of the liner. Tote can be reused, discarded or recycled.



4

Helpful hints

To fully automate complete dispense, use a tilt table to move the product towards the dispense fitting.

A 4x4 block can be put under the pallet to lift one side of the tote and move product forward or liner can be pulled up and to one side towards the end of the dispense and clamped. (see photo)

There is no need to remove the fill cap to vent the tote as product dispenses.

There is no need to unstrap for dispensing.

